

Power System: Analysis Control Electrical Engineering

Comprehensive Theory with Solved Examples

Civil Services Examination



MADE EASY Publications Pvt. Ltd.

Corporate Office: 44-A/4, Kalu Sarai (Near Hauz Khas Metro Station), New Delhi-110016

E-mail: infomep@madeeasy.in

Contact: 9021300500

Visit us at: www.madeeasypublications.org

Power System: Analysis Control

© Copyright, by MADE EASY Publications Pvt. Ltd.

All rights are reserved. No part of this publication may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photo-copying, recording or otherwise), without the prior written permission of the above mentioned publisher of this book.

First Edition: 2018 Second Edition: 2019 Third Edition: 2021

Reprint: 2023

Reprint: 2022

© All rights reserved by MADE EASY PUBLICATIONS PVT LTD. No part of this book may be reproduced or utilized in any form without the written permission from the publisher.

Contents

Power System: Analysis Control

Chapter 1	3.6 Flashover and Puncture Voltage93
Transmission Line Parameters & Corona	.1 3.7 Sag and Tension93
1.1 Transmission Line Parameters	Practice Questions 97
1.2 Special Case of Double Circuit Line	13 Chapter 4
1.3 Corona	21
Practice Questions	Underground Cables and Distribution Systems100
Chantan 2	4.1 Underground Cables 100
Chapter 2	4.2 Distribution Systems119
Steady State Performance of Transmission Lines	Practice Questions 127
2.1 Introduction	
2.2 The Short Transmission Line	Chapter 5
2.3 The Medium Transmission Line	Compensation Techniques, Voltage Profile Control & Power Factor Correction132
2.4 The Long Transmission Line	5.1 Compensation of Transmission Lines
2.5 Observations on the Wave Nature of Long Transmission Line	·
2.6 Equivalent T-model	57 5.3 Power Factor Improvement
2.7 Per Unit and Complex Representation of ABCD Parameters	<i>Practice Questions</i> 145
2.8 Concept of Travelling Waves	65 Chapter 6
2.9 Surges in Transmission Lines	•
2.10 Principle of Active & Reactive Power Transfer	
2.11 Power Angle Characteristics of Transmission Line	70 6.2 Per Unit System
Practice Questions	77 6.3 Change of Base
	6.4 Selection of Base Values
Chapter 3	6.5 Per Unit Load Impedance154
Insulators for Overhead Transmission 8	6.6 Single Line Diagrams
3.1 Introduction	83 Practice Questions
3.2 Concept of Toughened Glass	
3.3 Types of Insulators	Chapter 7
Voltage Distribution Over A String of Suspension Insulators	Load Flows157
	89 7.2 Rus Impedance Matrix 164

7.3	Load Flow Problem170	Chapter 9
7.4	BUS Classification172	Power System Stability241
7.5	Gauss-Siedel Method174	9.1 Introduction241
7.6	Flow Chart for Gauss Siedel Algorithm 177	9.2 Different Forms of Stability241
7.7	Newton Raphson Method180	9.3 Power Angle Diagram242
7.8	Flow Chart for Load Flow Solution	9.4 The Swing Equation244
	Using NR Method in Polar Coordinates184	9.5 Steady State Stability248
7.9	Decoupled Load Flow Studies186	9.6 Transient Stability
7.10	Fast Decoupled Load Flow (FDLF) Method 187	Practice Questions
7.11	Comparison between Gauss-Siedel and Newton-Raphson Method	Practice Questions268
Practice Questions190		Chapter 10
		Economic Operation of Power Systems 272
Ch	apter 8	10.1 Economics of Power Generation272
Fau	ılt Analysis 196	10.2 Economic Scheduling of Generating Units276
8.1	Introduction196	10.3 Optimal Operation of Generators on a Bus-Bar 277
8.2	Type of Faults in a Power System196	10.4 Special Cases
8.3	Single Line Diagram of a Power System Network 197	10.5 Transmission Loss as a Function of Plant Generation283
8.4	Method of Short-circuit Calculations	10.6 Representation of Transmission Loss by B-coefficients 284
	for Symmetrical Faults	Practice Questions289
8.5	Transient in a Series RL Circuit	
8.6	Short Circuit of a Synchronous Machine (on no-load)199	Chapter 11
8.7	Reactors	Static VAR System292
8.8	Short Circuit of a Loaded Synchronous Machine 204	11.1 Introduction292
8.9	,	11.2 Thyristor Controlled Reactor (TCR)
	Sequence Components of Voltage	11.3 Thyristor Switched Capacitor (TSC)
	Sequence Impedances of Transmission Lines 213	11.4 Fixed Capacitor, Thyristor Controlled Reactor (FC-TCR)301
8.12	Sequence Circuits and Impedances of Synchronous Machine	11.5 Comparison of Static VAR Generators 302
8.13	Sequence Impedance of a Transmission Line and their Representation217	Chapter 12
8.14	Sequence Network of a Transformer	Concepts of HVDC Transmission 303
	and its Sequence Impedances217	12.1 High Voltage DC Transmission (HVDC)303
	Unsymmetrical Faults on an Unloaded Generator 218	Practice Questions311
	Causes of Short Circuit Faults	
	Selection of Circuit Breakers	••••
	Algorithm for Short Circuit Study (ZBUS Based) 230	
rrac	tice Questions 236	

Transmission Line Parameters & Corona

1.1 Transmission Line Parameters

An electric transmission line has four parameters which affect its ability to fulfill its function as part of a power system, resistance, inductance, capacitance, and conductance. The "resistance" of transmission line conductors is the most important cause of power loss in a transmission line.

"Inductance" is by far the most dominant line parameter from power system engineer's view point which limits the transmission capacity of a line. The inductance of the circuit relates the voltage induced by changing flux to the rate of change of current. The "capacitance" which exists between the conductors is defined as the charge on the conductors per unit of potential difference between them. The fourth parameter, "conductance", exists between conductors or between conductors and the ground. Conductance accounts for the leakage current at the insulators of overhead lines and through the insulation of cables which is usually neglected as being very small.

Resistance of a Transmission Line

The term "resistance" in a transmission line usually means effective resistance.

The effective resistance of a conductor is

$$R = \left(\frac{\text{Power loss in conductor}}{|I|^2}\right)\Omega$$

The effective resistance is equal to the dc resistance of the conductor only if the distribution of current throughout the conductor is uniform.

Direct-current resistance is given by, $R_D = \left(\frac{\rho l}{A}\right)\Omega$

where, ρ = resistivity of conductor

l = length

A = cross-sectional area

The uniform distribution of current throughout the cross-section of a conductor exists only for direct current. As the frequency of alternating current increases, the non-uniformity of distribution becomes more pronounced. An increase in the frequency causes non-uniform current density. This phenomenon is called "skin effect" which is explained in next articles.

Electrical Engineering • Power System : Analysis Control



Types of Conductors

In present trend, aluminium conductors have completely replaced copper for overhead lines because of the much lower cost and lighter weight of an aluminium conductor compared with a copper conductor of the same resistance. Symbols identifying different types of aluminium conductors are as follows:

AAC : all-aluminium conductors

AAAC : all-aluminium-alloy conductors

ACSR: aluminium conductor, steel-reinforced ACAR: aluminium conductor, alloy-reinforced

ACSR

ACSR consists of a central core of steel strands surrounded by layers of aluminium strands. Fig. 1.1 shows the cross-section of a typical steel-reinforced aluminium cable (ACSR). The conductor shown has 7 steel strands forming a central core, around which there are two layers of aluminium strands. There are 24 aluminium strands in the two outer layers. The conductor stranding is specified as simply 24/7.

$$S = 3y^2 - 3y + 1$$

 $S \rightarrow Number of strands$

 $y \rightarrow$ Number of layers ≥ 2 i.e. y = 1 for central




Fig.1.1: Cross-sectional view of a steel-reinforced conductor, 7 steel strands, and 24 aluminium strands

Overall diameter of stranded conductor,

$$D = (2y - 1) d$$

where, $d \rightarrow$ uniform dia of a strand




- Aluminium-alloy conductors have higher tensile strength than the ordinary conductor grade of aluminium.
- The total number of strands in concentrically stranded cables, where the total annular space is filled with strands of uniform diameter is 7, 19, 37, 61, 91 or more.
- Various tensile strengths, current capacitances, and conductor sizes are obtained by using different combinations of steel and aluminium.
- A type of conductor called "expanded ACSR" has a filler such as paper separating the inner steel from the outer aluminium strands is being used for EHV lines.

Skin Effect and Proximity Effect

Skin effect: The distribution of current throughout the cross-section of a conductor, is uniform only when DC is passing through it. On the contrary when AC is flowing through a conductor, the current is non-uniformly distributed over the cross-section in a manner that the current density is higher at the surface of the conductor compared to the current density at its center. This effect becomes more pronounced as frequency is increased. This phenomenon is called skin effect. It causes larger power loss for a given rms AC than the loss when the same value of DC is flowing through the conductor. Consequently, the effective conductor resistance is more for AC than for DC.



Imagine a solid round conductor (a round shape is considered for convenience only) to be composed of annular filaments of equal cross-section area as shown in Fig. 1.2. The flux linking the filaments progressively decreases as we move towards the outer filaments for the simple reason that the flux inside a filament does not link it. The inductive reactance of the imaginary filaments therefore decreases outwards with the results that the outer filaments conduct more AC than the inner filaments (filaments being parallel). With the increase of frequency the non-uniformly of inductive reactance of the filaments become more pronounced, so also the non-uniformity of current distribution. For large solid conductors, the skin effect is quite significant even at 50 Hz.



Decreasing flux linkage/ inductive reactance (Increasing current density)

Fig.1.2: Skin effect

Proximity effect: Non-uniform current distribution in a conductor due to presence of other current carrying conductor in the vicinity is called proximity effect.

The fundamental reason for the proximity effect is the change in the net magnetic field around the nearly placed current carrying conductors. Since conductors carrying currents in same direction lead to the reduction in net magnetic field in between them and conductors with opposite currents result in increased field between them. Thus in prior case, current tries to be established densely in adjacent faces of the conductors due to less inductive reactance, while in later condition current density is lesser in adjacent faces w.r.t. remote portion of the conductor. Fig. 1.3 depicts the effect pictorially, for the later condition.




Fig. 1.3: Proximity effect



- Skin effect causes larger power loss for a given rms AC than the loss when the same value of DC is flowing through the conductor which is an undesirable effect.
- Due to skin effect, the effective conductor resistance becomes more for AC than for DC.
- "Proximity effect" and "Skin effect" both results in the increase in the resistance of conductor and decrease of self reactance.
- Both the effects depends on the conductor size, frequency of the supply, resistivity and relative permeability of the material.
- Proximity effect is more pronounced for large conductors, high frequencies and close proximity.
- Proximity effect is more pronounced in case of cables where the spacing between the conductors is small.



Inductance of Transmission Lines

Inductance

Voltage induced in a circuit is given by

where, Ψ represents the flux linkages of the circuit in Weber-turns (*Wb-T*).

Also.

$$e = \frac{d\Psi}{dt} \times \frac{di}{di} = L\left(\frac{di}{dt}\right)V$$

where, $L = \frac{d\Psi}{dt}$ is defined as the self *inductance of the circuit* in henry.

In a linear magnetic circuit, inductance is constant and is given by

$$L = \frac{\Psi}{i}$$
 Henry or $\Psi = Li$ Wb-T

For alternating current,

$$\lambda = LI$$

where, λ and I are the rms values of flux linkages and current respectively.

Similarly, mutual inductance between two circuits is defined as "the flux linkages of one circuit due to current in other circuit".

i.e.,
$$M_{12} = \frac{\lambda_{12}}{I_2} H$$

Also, voltage drop in circuit 1 due to current in circuit 2 is $V_1 = j\omega M_{12} I_2 = j\omega \lambda_{12} V$

Inductance of a Conductor Due to Internal Flux

The inductance of a transmission line is calculated as flux per ampere. To obtain an accurate value for the inductance of a transmission line, it is necessary to consider the flux inside each conductor as well as the external flux. Let us consider the long cylindrical conductor whose cross-section is shown in Fig. 1.4. Here, it is assumed that the lines of flux are concentric with the conductor.

By Ampere's law.

$$mmf = \oint H \cdot dS = I \quad At \qquad ...(1)$$

where.

H = magnetic field intensity, At/m

S = distance along path, m

I = current enclosed. A

Let the field intensity at a distance x meters from the center of the conductor be designated H_r . Since field is symmetrical, H_r is constant at all points equidistance from the center of the conductor.

Using equation (1) for Fig. 1.4, we have




Fig. 1.4: Cross-section of a cylindrical conductor

$$\oint H_r dS = I_r$$

$$\partial H_x dS = I_x \qquad ...(2)$$

$$2\pi x H_y = I_y \qquad ...(3)$$

and

where I_r is the current enclosed. Then, assuming uniform current density

$$I_x = \frac{\pi x^2}{\pi r^2} I$$
 (I = Total current in the conductor) ...(4)



Substituting I_{x} from equation (4) into equation (3), we have

$$2 \pi x H_x = \frac{\pi x^2}{\pi r^2} I$$
 or $H_x = \frac{x}{2\pi r^2} I$ At/m

:. Flux density x meter from the center of the conductor is

$$B_x = \mu H_x = \frac{\mu x I}{2\pi r^2} \text{Wb/m}^2$$
 ($\mu = \text{permeability of conductor}$) ...(5)

The flux per meter of length is, $d \phi = \frac{\mu x I}{2\pi r^2} dx$ Wb/m

 \therefore Flux linkage, $d\lambda$ per meter of length is

$$d\lambda = \frac{\pi x^2}{\pi r^2} d\phi = \frac{\mu I x^3}{2\pi r^4} dx \quad \text{Wbt/m} \qquad ...(6)$$

So,
$$\lambda_{\text{int}} = \int_0^r \frac{\mu I \, x^3}{2\pi \, r^4} \, dx = \frac{\mu I}{8\pi} \quad \text{Wbt/m} \qquad \dots (7)$$

Since, $\mu = 4\pi \times 10^{-7} \text{ H/m}$

therefore, $\lambda_{int} = \frac{I}{2} \times 10^{-7} \text{ Wbt/m}$

Flux Linkages Due to Flux between Two Points External to Conductor

For finding the external flux linkages, let us derive an expression for the flux linkages of an isolated conductor due to only that portion of the external flux which lies between two points at D_1 and D_2 meters from the center of the conductor. In Fig. 1.5, P_1 and P_2 are two such points. The conductor carries a current of I A.

At the tabular element, which is x meters from the center of the conductor, the field intensity is H_x . The mmf around the element is

$$2\pi x H_x = I$$
 or $H_x = \frac{I}{2\pi x}$ A/m

$$B_x = \mu H_x$$
 or $B_x = \mu \left[\frac{I}{2\pi x} \right] \text{Wb/m}^2$

The flux $d\phi$ in the tabular element of thickness dx is

$$d\phi = \frac{\mu I}{2\pi x} dx \text{ Wb/m}$$

Now, between points P_1 and P_2 , the flux linkage are

$$\lambda_{12} = \int_{D_1}^{D_2} \frac{\mu I}{2\pi x} \cdot dx = \frac{\mu I}{2\pi} In \left(\frac{D_2}{D_1}\right) \text{ Wbt/m}$$

or for a relative permeability of 1,

$$\lambda_{12} = 2 \times 10^{-7} I \ln \frac{D_2}{D_1}$$
 Wbt/m

The inductance only due to the flux induced between P_1 and P_2 is

$$L_{12} = 2 \times 10^{-7} In \left(\frac{D_2}{D_1}\right) H/m \qquad ...(Important result) \qquad ...(9)$$




Fig. 1.5: A conductor and external points P_1 and P_2



Inductance of a Single-phase Two-wire Line

Fig. 1.6 shows a line having two conductors of radii r_1 and r_2 . One conductor is the return circuit for the other. Here, D is much greater than r_1 and r_2 to assume that D can be used instead of $(D-r_2)$ or $(D+r_2)$.




Fig. 1.6: Conductors of different radii and the magnetic field due to current in conductor 1 only

Now, replacing D_1 with r_1 and D_2 with D in equation (9), the inductance due to external flux linkage is

$$L_{\text{ext}} = L_{12} = 2 \times 10^{-7} In \left(\frac{D}{r_1}\right) \text{ H/m} \text{ and } L_{\text{int}} = \frac{1}{2} \times 10^{-7} \text{ H/m}$$

Hence, inductance of the circuit of Fig. 1.6 due to the current in conductor 1 only is,

$$L_{1} = \left(\frac{1}{2} + 2In\frac{D}{r_{1}}\right) \times 10^{-7} \text{ H/m}$$
or,
$$L_{1} = 2 \times 10^{-7} \left(Ine^{1/4} + In\frac{D}{r_{1}}\right) \text{ H/m or } L_{1} = 2 \times 10^{-7} In\left(\frac{D}{r_{1}e^{-1/4}}\right) \text{ H/m}$$
Let,
$$r_{1}' = r_{1}e^{-1/4}, \text{ then}$$

$$L_{1} = 2 \times 10^{-7} In\left(\frac{D}{r_{1}'}\right) \text{ H/m} \qquad [\text{Inductance per conductor (if } r_{1}' = r')] \qquad ...(10)$$



The radius r_1' is that of a fictitious conductor assumed to have no internal flux but, with the same inductance as the actual conductor of radius r_1 .

Here, $e^{-1/4} = 0.7788$

The multiplying factor of 0.7788 applies only to solid round conductors.

Similarly, the inductance due to current in conductor 2 is

$$L_2 = 2 \times 10^{-7} ln \left(\frac{D}{r_2'}\right) H/m$$
 [Inductance per conductor (if $r_2' = r'$)] ...(11)

For complete circuit,
$$L_1 = L_1 + L_2 = 4 \times 10^{-7} \ln \left(\frac{D}{\sqrt{r_1' r_2'}} \right) \text{H/m}$$



or,

If $r_1' = r_2' = r'$, the total inductance reduces to

$$L = 4 \times 10^{-7} ln \left(\frac{D}{r'}\right) H/m$$
 ...(Inductance per loop meter)
 $L = 0.921 log \left(\frac{D}{r'}\right) mH/km$...(Important result) ...(12)

Inductance of Composite Conductor Lines

Fig. 1.7 shows a single-phase line comprising composite conductors A and B with A having 'n' parallel filaments and B having m' parallel filaments. It is assumed that the current is equally divided among the filaments of each composite conductor. Hence, each filament of A is taken to carry a current I/n, while each filament of conductor 'B' carries the return current of -I/m'.




Fig. 1.7: Single-phase line consisting of two composite conductors

Now, the total flux linkages of conductor i of composite conductor A is given by

$$\lambda_{i} = 2 \times 10^{-7} \cdot \frac{I}{n} \left[ln \frac{1}{D_{i_{1}}} + ln \frac{1}{D_{i_{2}}} + \dots + ln \frac{1}{D_{ii}} + \dots + ln \frac{1}{D_{in}} \right]$$

$$-2 \times 10^{-7} \cdot \frac{I}{m'} \left[ln \frac{1}{D_{i_{1}'}} + ln \frac{1}{D_{i_{2}'}} + \dots + ln \frac{1}{D_{ij'}} + \dots + ln \frac{1}{D_{im'}} \right]$$

$$= -2 \times 10^{-7} I ln \left(\frac{m \sqrt{D_{i_{1}} D_{i_{2}} \dots D_{im'}}}{\sqrt{D_{i_{1}} D_{i_{2}} \dots D_{ii}} \dots D_{in}} \right) \text{ Wb-T/m}$$

The inductance of filament *i* is then,

$$\frac{\lambda_i}{I/n} = 2n \times 10^{-7} ln \left(\frac{m\sqrt{D_{i1'}...D_{ij}...D_{im'}}}{\sqrt[n]{D_{i1}...D_{ii}}} \right) H/m \qquad ...(13)$$

Now, the average inductance of the filament of composite conductor A is

$$L_{\text{avg}} = \frac{L_1 + L_2 + L_3 + ... + L_n}{n}$$

Since conductor A is composed of n filaments electrically in parallel, it's inductance is

$$L_{A} = \frac{L_{avg}}{n} = \left(\frac{L_{1} + L_{2} + \dots + L_{n}}{n^{2}}\right)$$
 ...(14)

Substituting the logarithmic expression for filament inductance from equation (13) in equation (14), we have

$$L_{A} = 2 \times 10^{-7} ln \left(\frac{m' \sqrt{(D_{11'}...D_{1j'}...D_{1m'})(D_{i1'}...D_{ij'}...D_{im'})(D_{n1'}...D_{nj'}...D_{nm'})}}{\sqrt{(D_{11}...D_{1j}...D_{1m})(D_{i1}...D_{ii}...D_{in})(D_{n1}...D_{nj}...D_{nn})}} \right) H/m \qquad ...(15)$$

The numerator of the argument of the logarithm in equation (15) is the $m'n^{th}$ root of the m'n terms i.e. it is the products of all possible mutual distances from the n filaments of a conductor A to m' filament of conductor B. This is called "mutual geometric mean distance (mutual GMD)" (denoted by D_m).



The denominator is defined as the **self geometric mean distance (self GMD)** of conductor. Sometimes, self GMD is also called "geometric mean radius (GMR)" (denoted by D_s).

In terms of D_m and D_s , equation (15) can be written as

$$L_A = 2 \times 10^{-7} \ln \left(\frac{D_m}{D_s} \right) \text{H/m} = 0.461 \log \frac{D_m}{D_s} \text{ mH/km} \qquad ... \text{(Important result)} \qquad ... \text{(16)}$$

The inductance of the composite conductor B is determined in a similar manner, and the total inductance of the line is given by

$$L = L_A + L_B$$



The inductance of one conductor of a single-phase line is $L(\text{inductance per conductor}) = 2 \times 10^{-7} In \left(\frac{D}{r'}\right) \text{ H/m}$

=
$$2 \times 10^{-7} In \left(\frac{\text{Mutual GMD}}{\text{Self GMD}} \right) \text{H/m}$$
 ...(Important result)

The inductance of a single-phase line is

$$L(\text{inductance per loop meter}) = 4 \times 10^{-7} ln \left(\frac{\text{GMD}}{\text{GMR}}\right) \text{H/m}$$

or,
$$4 \times 10^{-7} In \left(\frac{\text{Mutual GMD}}{\text{Self GMD}} \right) H/m$$
 ...(Important result)

Inductance of Three-phase Lines

Case-I

Equilateral spacing between conductors:

Fig. 1.8 shows the conductors of a three-phase line spaced at the corners of an equivalent triangle. For balanced three-phase phasor currents, $I_a + I_b + I_c = 0$.

Now, flux linkages of conductor a is




Fig. 1.8: Cross-sectional view of the symmetrically/equilaterally spaced conductors of a three-phase line

$$\lambda_a = 2 \times 10^{-7} \left(I_a ln \frac{1}{D_s} + I_b ln \frac{1}{D} + I_c ln \frac{1}{D} \right) \text{Wbt/m}$$
 Since,
$$I_a = -(I_b + I_c), \text{ therefore, above equation becomes}$$

$$\lambda_a = 2 \times 10^{-7} \left(I_a ln \frac{1}{D_s} - I_a ln \frac{1}{D} \right) = 2 \times 10^{-7} I_a ln \left(\frac{D}{D_s} \right) \text{Wbt/m}$$
 So,
$$L_a = 2 \times 10^{-7} ln \left(\frac{D}{D_s} \right) \text{H/m} \qquad ...(17)$$



Due to symmetry, the inductance of conductors b and c will be equal to the inductance of conductor a

So,
$$L_a = L_b = L_c = 2 \times 10^{-7} ln \left(\frac{D}{D_s}\right) H/m$$



■ Since each phase consists of single conductor therefore, the inductance per phase of the three-phase line will be equal to that due to any one phase.

i.e.,
$$L_{(3-\phi \text{ line})} = L_a = L_b = L_c$$

$$= 2 \times 10^{-7} \ln \left(\frac{D}{D_c}\right) \text{H/m}$$

Case-II

Unsymmetrical spacing between conductors: When the conductors of a three-phase line are unsymmetrically spaced, the flux linkages and inductance of each phase are not the same. The different inductance in each phase give rise to an unbalanced circuit. The three-phase circuit can again be balanced with the help of "transposition".

Transposition of Transmission Lines

Transposition of a transmission line (3-phase line) is defined as "exchange of conductor positions at regular intervals along the line so that each conductor occupies the original position of each other conductor over an equal distance."

An unsymmetrically spaced 3-phase conductors with it's transposition cycle is shown in Fig. 1.9.




Fig. 1.9: An unsymmetrically spaced 3-phase conductors with it's transposition cycle

From Fig. 1.9, flux linkage of conductor a in position 1 when b is in position 2 and c is in position 3 is given by

$$\lambda_{a_1} = 2 \times 10^{-7} \left(I_a ln \frac{1}{D_s} + I_b ln \frac{1}{D_{12}} + I_c ln \frac{1}{D_{31}} \right) \text{Wbt/m}$$

when a is in position 2, b in position 3, and c in position 1, then

$$\lambda_{a_2} = 2 \times 10^{-7} \left(I_a ln \frac{1}{D_s} + I_b ln \frac{1}{D_{23}} + I_c ln \frac{1}{D_{12}} \right) \text{Wbt/m}$$

when a is in position 3, b in position 1, and c in position 2, then

$$\lambda_{a_3} = 2 \times 10^{-7} \left(I_a ln \frac{1}{D_s} + I_b ln \frac{1}{D_{31}} + I_c ln \frac{1}{D_{23}} \right) \text{Wbt/m}$$

Now, the average value of the flux linkage of a is, $\lambda_a = \left(\frac{\lambda_{a_1} + \lambda_{a_2} + \lambda_{a_3}}{3}\right)$

or,
$$\lambda_a = \frac{2 \times 10^{-7}}{3} \left(3I_a \ln \frac{1}{D_s} + I_b \ln \frac{1}{D_{12} D_{23} D_{31}} + I_C \ln \frac{1}{D_{12} D_{23} D_{31}} \right)$$
 since,
$$I_a = -(I_b + I_c)$$
 therefore,
$$\lambda_a = \frac{2 \times 10^{-7}}{3} \left[3I_a \ln \frac{1}{D_s} - I_a \ln \left(\frac{1}{D_{12} D_{23} D_{31}} \right) \right]$$

$$= 2 \times 10^{-7} I_a \ln \left(\frac{\sqrt[3]{D_{12} D_{23} D_{31}}}{D_s} \right)$$
 Wbt/s



So, average inductance per phase is

$$L_a = 2 \times 10^{-7} In \left(\frac{D_{eq}}{D_s} \right) H/m$$
 ...(18)

where,

$$D_{eq} = \sqrt[3]{D_{12} \, D_{23} \, D_{31}}$$

 $= D_m = Mutual GMD$ of the three-phase conductors

and

 $D_s = \text{GMR}$ or self GMD of the conductor

Example-1.1 A three-phase, fully transposed, 50 Hz, 110 kV, transmission line has horizontal spacing of 3.5 m between adjacent conductors of diameter 1.05 cm. Find the capacitance per phase and charging current per km of line.

Solution:

The equivalent spacing,


$$D_{eq} = (3.5 \times 3.5 \times 7)^{1/3} = 4..41 \text{ m}$$

Radius of conductor,

$$r = \frac{1}{2} \times 1.05 \times 10^{-2} = 5.25 \times 10^{-3} \text{ m}$$

Capacitance per phase = Capacitance to neutral (C_n)

$$C_n = \frac{2\pi\varepsilon}{\ln\frac{D_m}{r}}$$



Here,

 D_m = mutual geometric mean distance (= D_{eq})

.•.

$$D_{m} = 4.41 \text{ m}$$

$$C_n = \frac{2\pi\varepsilon_0\varepsilon_r}{\ln\frac{D_m}{r}} = \frac{2\pi\times8.854\times10^{-12}}{\ln\frac{4.41}{5.25\times10^{-3}}} = 8.26\times10^{-12} \text{ F/m}$$
$$= 8.26\times10^{-9} \text{ F/km}$$

Capacitive reactance per phase,

$$X_c = \frac{1}{2\pi f C_0} = \frac{1}{2\pi \times 50 \times 8.26 \times 10^{-9}} = 3.853 \times 10^5 \,\Omega/\text{km}$$

Charging current,

$$I_c = \frac{V}{X_c} = \frac{110 \times 10^3 / \sqrt{3}}{3.853 \times 10^5} = 0.1648 \text{ A/km}$$

Example-1.2 Determine the inductance of a 3-phase line operating at 50 Hz. Phase conductors of the line having diameter 0.8 cm and arranged at the vertices of an isosceles triangle of sides 1.6 m, 1.6 m and 3.2 m.

Solution:


As given, configuration of three-phase conductors is shown in the figure.

The self GMD of the conductor $(D_S) = \frac{0.7788 \times 0.8}{2 \times 100} = 0.003115 \text{ m}$

The mutual GMD of the conductor (D_m) = $\sqrt[3]{1.6 \times 3.2 \times 1.6} = 2.016 \,\text{m}$

:. Inductance per km =
$$2 \times 10^{-7} ln \frac{2.016}{0.003115}$$

= 1.294 mH/km







- Over the length of one transposition cycle, the total flux linkages and hence net voltage induced in a nearby telephone line is zero i.e. transposition of transmission line eliminates radio-interference in the nearby communication lines.
- Practical transmission lines are not transposed although an interchange in the positions of the conductors may be made at switching stations in order to balance the inductance of the phases more closely. For all practical purposes the dissymmetry can be neglected and the inductance of an untransposed line can be taken equal to that of a transposed line.
- For unsymmetrical spacing between the 3-phase conductors, mutual GMD of the circuit increases due to which inductance of the line is increased. This gives rise to the increase in the inductive reactance of the transmission line.

We know that, power transmitted from the sending to the receiving end is

$$P = \frac{|V_{\rm S}||V_{R}|}{X} \sin \delta$$

Due to increase in X, P is decreased i.e. power transmission capability of the transmission line is reduced therefore, conductors of the 3-phase line must be arranged in symmetrical configuration.

Bundled Conductors

A "bundled conductor" is a conductor made up of two or more conductors, called sub-conductors, per phase in close proximity compared with the spacing between phases. In lines of 400 kV and higher voltages instead of going for a hollow conductor it is preferable to use more than one conductor per phase which is called bundling of conductors.

Fig. 1.10 shows the arrangement of a bundled conductor consisting of two, three, or four sub-conductors.





Fig. 1.10: Bundle conductor arrangements

Let D_s be the GMR of the individual conductors and D_s^b be the GMR of bundled conductor then

For a two-stranded bundle conductor, $D_s^b = \sqrt[4]{(D_s \times d)^2} = \sqrt{D_s \times d}$

For a three-stranded bundle conductor, $D_s^b = \sqrt[9]{(D_s \times d \times d)^3} = \sqrt[3]{D_s \times d^2}$

Example-1.3 Determine the inductance per km per phase of a single circuit 400 kV line having two bundled conductors per phase as shown in figure. The diameter of each conductor is 5.0 cm.







Important Expressions

1. Inductive per conductor is given by

$$L_1 = 2 \times 10^{-7} ln \left(\frac{D}{r_1'}\right) H/m; \quad L_2 = 2 \times 10^{-7} ln \left(\frac{D}{r_2'}\right) H/m$$

Hence, inductance per loop meter is given by

$$L = 4 \times 10^{-7} In \left(\frac{D}{r'}\right) H/m \quad (r'_1 = r'_2 = r)$$

or,

$$L = 0.921 \log \left(\frac{D}{r'}\right) \text{ mH/km}$$

2. For a composite conductor,

Inductor per loop meter =
$$2 \times 10^{-7} ln \left(\frac{GMD}{GMR} \right) H/m = 2 \times 10^{-7} ln \left(\frac{Mutual GMD}{Sefl GMD} \right) H/m$$

Line-to-line capacitance is given by $C_{ab} = \frac{\pi \varepsilon}{l \ln \left(\frac{D}{L}\right)} F/m$ 3.

- Line-to-line ground capacitance is given by $C_n = C_{an} = C_{bn} = \frac{2\pi\epsilon}{In\left(\frac{D}{r}\right)}$ F/m = $\frac{0.0242}{log\left(\frac{D}{r}\right)}$ µF/km 4.
- 5. If there is non-uniform distribution of charge on the surface of each conductor then,

$$C_n = \frac{2\pi \varepsilon}{In \left[\frac{D}{2r} + \sqrt{\left(\frac{D^2}{4r^2} - 1 \right)} \right]} F/m$$

- 6. Charging current per phase is given by, $I_{cha} = j\omega C_n V_{an} A/m$
- 7. When the effect of earth is taken into account then,

$$C_n = \frac{2\pi\varepsilon}{In\left[\frac{D}{r\left(1 + \frac{D^2}{4h^2}\right)}\right]}$$
 (Line-to-neutral capacitance)



and

$$C_{ab} = \frac{\pi \varepsilon}{In \left[\frac{D}{r \left(1 + \frac{D^2}{4h^2} \right)^{1/2}} \right]}$$
 (Line-to-line capacitance)

- 8. For a bundled conductor, $C_n = \frac{2\pi \varepsilon}{ln\left(\frac{D_{eq}}{D_{ec}^b}\right)}$ F/m
- 9. Corona:
 - Air density factor is, $\delta = \left(\frac{3.92 h}{t + 273}\right)$
 - Breakdown strength of air at NTP = 30 kV/cm/peak = 21.1 kV/cm/rms = g_0
 - At any temperature and pressure, critical disruptive voltage is given by $\left[V_{d_0} = g_0 \delta m_0 r \ln\left(\frac{d}{r}\right)\right]$


or,
$$\left[V_{d_0} = 21.1 r \delta m_0 l n \left(\frac{d}{r} \right) \text{ kV/cm/rms per phase} \right]$$

- Visual critical voltage is, $V_V = g_0 \, \delta r M_V \left(1 + \frac{0.3}{\sqrt{\delta r}} \right) In \left(\frac{d}{r} \right)$ kV (rms) to neutral
- Corona power loss is given by $\left[P_C = \frac{244}{8} \left(f + 25 \right) \sqrt{\frac{r}{d}} \left(V_{ph} V_{d0} \right)^2 \times 10^{-5} \text{ kW/km/phase} \right]$



Practice Questions

- Q.1 (a) Find the inductance per km of a double circuit 3φ line as shown in the figure below. The transmission line is transposed within each circuit and each circuit remains on its ownside. Diameter of each conductor is 15 mm.
 - **(b)** Explain why the given arrangment is better as compared to when conductors of the same phase are placed in the same horizontal plane.





- Q.2 A 3ϕ 50 Hz, 132 kV transmission line consists of conductors of 1 cm diameter and spaced equilateral at distance of 2 meters. The line conductors have smooth surface with value for m = 0.9. The barometric pressure is 72 cm of Hg and temperature is 25°C. Find:
 - (a) Critical disruptive voltage
 - (b) Corona loss per km per phase

Solve this for both conditions (i) fair weather, (ii) bad weather.


Practice Questions Explanations

1. Solution:

(a) As we know that inductance per phase

$$L_{ph} = 2 \times 10^{-7} \ln \left(\frac{D_{m_1} D_{m_2} D_{m_3}}{D_{s_1} D_{s_2} D_{s_3}} \right)^{1/3}$$

Diameter = 15 mm, $r = 7.5 \times 10^{-3}$




$$D_{m_1} = \left[\left(D_{R_1Y_1} D_{R_1Y_2} D_{R_1B_1} D_{R_1B_2} \right) \left(D_{R_2Y_1} D_{R_2Y_2} D_{R_2B_1} D_{R_2B_2} \right) \right]^{1/2 \times 4}$$

$$D_{m_1} = [(3.25 \times 6.93 \times 6 \times 5) \times (6.93 \times 3.25 \times 5 \times 6)]$$

= 5.09 m

$$\begin{split} D_{\text{S1}} &= \left[\left(D_{R_1 R_1} D_{R_1 R_2} D_{R_2 R_1} D_{R_2 R_2} \right) \right]^{1/4} \\ &= \left[0.7788 \times 7.5 \times 10^{-3} \times 7.81 \times 0.7788 \times 7.5 \times 10^{-3} \times 7.81 \right]^{1/4} \\ D_{\text{S1}} &= 0.2135 \, \text{m} \end{split}$$

For D_{m_2} , D_{s_2}



$$D_{m_2} = [(3.25 \times 6.93 \times 3.25 \times 6.93) \times (6.93 \times 3.25 \times 6.93 \times 3.25)]^{1/8}$$


= 4.75 m

$$D_{s2} = [0.7788 \times 7.5 \times 10^{-3} \times 7.5 \times 0.7788 \times 7.5 \times 10^{-3} \times 7.5]^{1/4}$$

$$D_{s2} = 0.2093 \,\mathrm{m}$$




For D_{m_3} , D_{s_3}




Now,

$$L_{ph} = 2 \times 10^{-7} \ln \left[\frac{5.09 \times 5.09 \times 4.75}{0.2135 \times 0.2135 \times 0.2093} \right]^{1/3} = 0.63 \text{ mH/km/ph}$$

(b) Conductors are in diagonally placed.



Conductors in same horizontal line.



Comparison:

- 1. If conductors are diagonally placed as shown in figure, self GMD is increased because spacer length S_1 is more compared to S_2 .
- 2. Inductance per phase is reduced, because of increase in self GMD.
- 3. Power transfer capability is inversely proportional to inductance so power capability increased. Because of above advantages instead of horizontal plane, arragement in Fig. 1 is used.



2. **Solution:**

(i) Fair weather, f = 50 Hz

Phase voltage =
$$\frac{132 \times 10^{3}}{\sqrt{3}}$$
 = 76.21kV

Diameter of conductor = 1 cm

Radius of conductor =
$$\frac{1}{2}$$
 = 0.5 cm = 0.5 × 10⁻² m

Conductor spacing = 2 m

Surface regularly factor, m = 0.9

Air density correction factor,
$$\delta = \frac{3.92b}{273+t} = \frac{3.92 \times 72}{273+25}$$
$$= 0.9471$$
$$g = 21.1 \text{ kV/cm}$$

Now, Critical disruptive voltage, $V_{d0} = mgr\delta \ln \left(\frac{d}{r}\right)$

=
$$0.9 \times 21.1 \times 0.5 \times 0.947 \ln \left(\frac{2}{0.5 \times 10^{-2}} \right) \text{kV/ph (RMS)}$$

$$V_{d0} = 53.87 \,\text{kV/ph} \,(\text{RMS})$$

$$P_L = 242.2 \times 10^{-5} \left(\frac{50 + 25}{0.9471} \right) \sqrt{\frac{0.5 \times 10^{-2}}{2}} (76.21 - 53.87)^2 \text{kW/km/ph}$$

$$P_L = 4.786 \, \text{kW/km/phase}$$

(ii) For foul weather,

Now.

For foul weather condition,

Critical disruptive voltage =
$$0.8 \times V_{00}$$

$$V'_{d0} = 0.8 \times V_{d0}$$

 $= 43.096 \, kV/ph \, (RMS)$

Corona loss,
$$P_L = 242.2 \times 10^{-5} \left(\frac{f + 25}{\delta} \right) \sqrt{\frac{r}{d}} \left(V_{ph} - V'_{d0} \right)^2$$

$$P_L = 242.2 \times 10^{-5} \left(\frac{50 + 25}{0.9471} \right) \sqrt{\frac{0.5 \times 10^{-2}}{2}} (76.21 - 43.096)^2$$

$$P_L = 10.515 \text{ kW/km/phase}$$